

DIAMOND TOOLS

<i>IMPREGNATED DIAMOND BITS</i>	<i>SURFACE SET DIAMOND BITS</i>	<i>IMPREGNATED DIAMOND CASING SHOES</i>	<i>DIAMOND REAMING SHELLS</i>	<i>DIAMOND LOCKING COUPLINGS</i>	<i>PDC CORING BITS</i>
<i>BWL</i>	<i>BWL</i>	<i>BW</i>	<i>BWL</i>	<i>BWL</i>	<i>NWL</i>
<i>NWL</i>	<i>NWL</i>	<i>NW</i>	<i>NWL</i>	<i>NWL</i>	<i>HWL</i>
<i>HWL</i>	<i>HWL</i>	<i>HW</i>	<i>HWL</i>	<i>HWL</i>	<i>46</i>
<i>PWL</i>	<i>PWL</i>	<i>PW</i>	<i>PWL</i>		<i>50</i>
<i>NWL3</i>	<i>NWL3</i>	<i>BWL</i>			<i>56</i>
<i>HWL3</i>	<i>HWL3</i>	<i>NWL</i>			<i>60</i>
<i>PWL3</i>	<i>PWL3</i>	<i>HWL</i>			<i>66</i>
		<i>PWL</i>			<i>76</i>



TC TOOLS

WIRELINE	CONVENTIONAL					CASING SHOES
	B SINGLE TUBE	WG SINGLE TUBE	T DOUBLE TUBE	WM DOUBLE TUBE	T6 S SPLIT TUBE	
BWL	B 46	BWG	T 46	BWM	T6 S 86	BW
NWL	B 56	NWG	T 56	NWM		NW
HWL	B 66		T 66			HW
PWL	B 76		T 76			PW
	B 86		T 86			
	B 101		T 101			
	B 116					
	B131					

